# Roller System

Cat# 38IGT

ASSEMBLY INSTRUCTIONS

# Includes:



# General Dimensions



W

W/2 +7/8"

(Track Lenght)
W-1-1/4"

H-3-3/4"

H

W/2 + 7/8"

**IGT**
glasshardware.com

**Assembly
Instructions:**
ROLLER SYSTEM
CAT# 38IGT

**p. 2**

**1.**

Identify distance between panel holes ⚠

?

4-3/8"

?

5"

FIXED PANEL

⚠ Refer to fabrication template

**2.**

**3.**

**4.**

**IGT**
glasshardware.com

**Assembly Instructions:**
ROLLER SYSTEM
CAT# 38IGT

**p. 3**

**5.**



**6.**



**7.**



**8.**

**Assembly
Instructions:**
ROLLER SYSTEM
CAT# 38IGT

IGT
glasshardware.com

**p. 4**

**9.**



**10.**



**11.**



**12.**

IGT
glasshardware.com

**Assembly
Instruction**
ROLLER SYSTEM
CAT# 38IGT

**p. 5**

**13.**



**14.**



**Move to adjust the desired position of the door.**

**When position is found, tighten to secure.**

**13.**



**When position is found, tighten to secure.**

**Adjust to eliminate gap between roller and track.**

**Assembly Instructions:**
ROLLER SYSTEM
CAT# 38IGT

**rGT**
glasshardware.com

**p. 6**